




Reprogramming a Liberty³⁰⁰ alarm from landline (POTS/PSTN) to cellular (GSM) connection

Please ensure the alarm has a SIM card already installed. If the alarm does not have a SIM card, please contact Tunstall to arrange one.

To enter programming mode:

1. First, switch the Liberty³⁰⁰ unit off at the mains power and battery under the alarm, wait five seconds, then switch both back on.
 - a. The unit will display version number, e.g. '1.8', for two seconds and beep once.
 - b. The unit will then display '_A' to indicate it is in programming mode. Note: the unit will switch to normal operating mode if no buttons are pressed within one minute.

To program the reporting mode:

2. Scroll through the main menu options by pressing the CANCEL (green) button until you reach the reports menu (12 times) , then press the HELP (red) button to select.
 - a. If you pass the _r, just keep pressing the green cancel button until _r is displayed again.
3. Press the HELP button to enter the reports sub-menu .
4. Press the HELP button until you reach 0 (GSM only).
5. Store this option by pressing the CANCEL button and HELP button together. The unit will beep three times and display the selected option.
6. Press the CANCEL button until  is displayed on the screen and then press the help (red) button. The alarm is now configured for cellular (GSM) connectivity to Tunstall.
7. IMPORTANT - Press the pendant to test the unit and inform the Tunstall monitoring centre that you have reprogrammed the alarm to GSM.